

BLUE'LOG XM / XC

OPTIONAL LICENSES



DESCRIPTION OF FUNCTIONS

The functionality of blue'Log XM / XC can be extended with a number of optional licenses.

For detailed information regarding each license, visit www.meteocontrol.com.

FEATURES

- + Extension of blue'Log XM / XC functionality
- + Licenses are linked to a specific device. The serial number of the blue'Log applies for identification
- + Licenses have no expiration date
- + Within the scope of a repair (RMA), you can request a transfer of your existing licenses from the defective blue'Log to the replacement device

OPTIONAL LICENSES

557005 OpenVPN license blue'Log XM / XC

557006 SFTP / FTP-Push license blue'Log XM / XC

557007 IT infrastructure license (LDAP, SCEP, SSL)

557008 Modbus Power Control license blue'Log XC

557009 SCADA Interface license blue'Log XM / XC

557 010 Automatic grid disconnection license blue'Log XC

557 011 WEB'log Slave mode license blue'Log XM

557012 Modbus configurator license blue'Log XM / XC

557013 External PPC blue'Log license XM / XC

Remote Power Control¹⁾

557 122 Remote Power Control license ≤ 200 kW blue'Log XC

557 123 Remote Power Control license ≤ 1 MW blue'Log XC

557 124 Remote Power Control license ≤ 3 MW blue'Log XC

557 125 Remote Power Control license ≤ 5 MW blue'Log XC

557 126 Remote Power Control license ≤ 10 MW blue'Log XC

557 127 Remote Power Control license ≤ 20 MW blue'Log XC

557 128 Remote Power Control license ≤ 50 MW blue'Log XC

557 129 Remote Power Control license ≤ 100 MW blue'Log XC

557131 Remote Power Control license Utility blue'Log XC

¹⁾ Maximum AC active power of the plant

LICENSE UPLOAD

- + Order the required license
- + Once ordered, meteocontrol will send the license by email
- + To activate the license, you must upload the license file to the corresponding blue'Log
- + Upload the license in the menu **System > License**
- + If activation is successful, a green check mark appears in the table **Installed licenses**

Licence upload



When changing the license from X-Monitoring to X-Control, the data logger is reset to its factory settings.

Select file

Upload licence

PLACING AN ORDER

Contact meteocontrol Order Management to order licenses. When ordering, please provide the 14-digit hardware serial number of your data logger.

Please note that licenses issued for a specific blue'Log XM / XC cannot be used for any other device.

Phone + 49 821 34666-43
order@meteocontrol.com

Further information: www.meteocontrol.com